# **BIG TREE TECH**

# BIGTREETECH 42 Stepper Motor Closed Loop Driver Board Manual

## Contents

<u> — Product introduction</u>
<u> — Product parameters3</u>
<u>≓</u> 、Features3
四、Interface Description4
五、Key Function5
六、Parameter adjustment
六、Parameter adjustment
<b>A</b> Parameter adjustment
六、Parameter adjustment
六、Parameter adjustment
六、Parameter adjustment

#### — . product introduction

The closed-loop drive of the stepper motor uses closed-loop control technology. The ATSAMD 21G18A is the main controller, the A4954 is the motor driver, and the AS5047D is the magnetic encoder. The closed-loop drive is to feedback the rotation angle of the stepping motor to the control panel, compare the distance that needs to be rotated with the distance of the actual rotation, calculate the error value, and then compensate, so as to prevent the problem of multi-step and lost step. The closed-loop drive can completely overcome the lost step of the open-loop stepping motor, and can also significantly improve the performance of the motor at high speed, thereby improving the processing speed and accuracy of the machine. When the motor is out of step for a long time, the main control chip can detect the step-out condition of the stepping motor through the magnetic encoder, thereby compensating, so that the machine can continue to work normally.

.the product parameters
Motor Power Supply (VM): 12V---24V
Motor default operating current: 800mA
Motor default standby current: 500mA

3 / 23

Drive segmentation default: 16 segments Subdivision steps: 1 2 4 8 16 32 64 128 256 Maximum current: 2000mA

**Ξ**.product features

1. The whole set of products is sold, eliminating the complicated assembly and debugging, and plug and play.

2, can not lose steps in high-speed printing.

3. Low heat generation and high operating efficiency.

- 4, easy to install, easy to wire.
- 5. Compared with ordinary drives, the motor runs more stably.

6. In the case of OLED, the current and subdivision of the motor can be modified by pressing the button. The operation is simple,

and the parameter adjustment can also be performed using USB.

7. In the case of no OLED, you can use USB to connect to the computer and adjust the parameters by command.



## 四、 the interface description

#### 五、Key Function

#### **RESET:** reset button

#### K1: Confirm selection (only valid in the setting interface)

#### K2: Switch settings interface and status interface

K3: Select the next line option (only valid in the settings interface)

## 六、parameter adjustment

Note: 42 stepping motor closed-loop drive control

## board has two parameter adjustment methods 1

OLED button adjustment method

Advantages: no need to connect to a computer, through OLED

display, button settings, simple and intuitive operation.

# Status interface



1) The first line, 0 RPM, represents the current number of revolutions per revolution.

2) .The second line, 0.00 err, represents the error between the actual position and the target position of the motor.

3 ) The third line, 000.0deg, represents the current target position of the motor is 0  $^{\circ}$ .

4) Setting interface



There are a total of 7 options in the settings interface.

## **Calibrate:**

The encoder is rotated 200 times (1.8 °each time) to calibrate the encoder. After the first power-on, the parameters must be calibrated.

#### Test Cal:

Test calibrate and report the maximum error in degrees

## Motor mA

Set the current when the motor is running, default 800MA

## Hold mA

Set the current when the motor is in standby, the default is 500MA

## Microstep,

Set segmentation, default 16 segments

## EnablePin

Set the logic level of the enable signal, Enable represents the high level enable, !Enable represents the low level enable, default !Enable low enable

## DirPin

Set the logic level of the dir signal. Modify this option to change the direction of rotation of the motor.

## Key

**RESET**: resetting key

K2: Switch settings interface and status interface

K3: Select the next line option (only valid in the settings interface)

K1: Confirm selection (only valid in the setting interface)

2、Command line adjustmentAdvantages: the parameters that can be set are more detailed

After connecting the computer, check if the driver is installed.



If the display is normal, you do not need to install the following drivers

## 2.1 Solutions for abnormal driver

Driver download website:

https://github.com/bigtreetech/BIGTREETECH-SERVO42A

-V1.0

## According computer system to install driver

名称	修改日期	类型	大小
퉬 amd64	2019/3/11 16:44	文件夹	
FTDI USB Drivers	2019/3/11 16:44	文件夹	
퉬 ia64	2019/3/11 16:44	文件夹	
퉬 license	2019/3/11 16:44	文件夹	
鷆 x86	2019/3/11 16:44	文件夹	
🥏 arduino.cat	2016/3/9 16:11	安全目录	11 KB
🗿 arduino.inf	2016/3/9 16:11	安装信息	10 KB
🥪 arduino_gemma.cat	2016/3/9 16:11	安全目录	11 KB
🗿 arduino_gemma.inf	2016/3/9 16:11	安装信息	8 KB
arduino-org.cat	2016/3/9 16:11	安全目录	9 KB
📰 arduino-org.inf	2016/3/9 16:11	安装信息	8 KB
💐 dpinst-amd64.exe	2016/3/9 16:11	应用程序	1,024 KB
💐 dpinst-x86.exe	2016/3/9 16:11	应用程序	90 <mark>1 K</mark> B
🔐 genuino.cat	2016/3/9 16:11	安全目录	9 KB
🗑 genuino.inf	2016/3/9 16:11	安装信息	5 KB
📑 Old_Arduino_Drivers.zip	2016/3/9 16:11	360压缩 ZIP 文件	17 KB
README.txt	2016/3/9 16:11	文本文档	1 KB

## 2.2 Serial Port Debugging Guide

(1)After the driver is ready, open the firmware with the arduino

IDE

名称	修改日期	类型	大小
🥺 stepper_nano_zero.ino	2019/3/11 17:48	Arduino file	1 KB
glcdfont.c	2019/3/11 17:48	C Source File	9 KB
🔂 A4954.cpp	2019/3/11 17:48	C++ Source File	10 KB
🔂 A5995.cpp	2019/3/11 17:48	C++ Source File	7 KB
Adafruit_GFX.cpp	2019/3/11 17:48	C++ Source File	32 KB
Adafruit_SSD1306.cpp	2019/3/11 17:48	C++ Source File	24 KB
💼 as5047d.cpp	2019/3/11 17:48	C++ Source File	8 KB
👩 calibration.cpp	2019/3/11 17:48	C++ Source File	13 KB
👩 command.cpp	2019/3/11 17:48	C++ Source File	9 KB
👩 commands.cpp	2019/3/11 17:48	C++ Source File	37 KB
c eeprom.cpp	2019/3/11 17:48	C++ Source File	8 KB
🔂 fet_driver.cpp	2019/3/11 17:48	C++ Source File	36 KB
🔁 Flash.cpp	2019/3/11 17:48	C++ Source File	5 KB
🔂 ftoa.cpp	2019/3/11 17:48	C++ Source File	4 KB
🔂 nonvolatile.cpp	2019/3/11 17:48	C++ Source File	5 KB
c nzs.cpp	2019/3/11 17:48	C++ Source File	19 KB
🔂 nzs_lcd.cpp	2019/3/11 17:48	C++ Source File	11 KB
🔂 planner.cpp	2019/3/11 17:48	C++ Source File	5 KB
💼 sine.cpp	2019/3/11 17:48	C++ Source File	12 KB
👩 stepper_controller.cpp	2019/3/11 17:48	C++ Source File	40 KB
👩 steppin.cpp	2019/3/11 17:48	C++ Source File	7 KB
👩 syslog.cpp	2019/3/11 17:48	C++ Source File	6 KB
💼 utils.cpp	2019/3/11 17:48	C++ Source File	2 KB
cproject	2019/3/11 17:48	CPROJECT 文件	13 KB
🥘 A4954.h	2019/3/11 17:48	H 文件	3 KB
🥮 A5995.h	2019/3/11 17:48	H 文件	2 KB
man to be open	0010/0/11 17 10	· · <u></u> 10	E 1/2

## ②Install development board

and providence of the								
e Edit Sketch To	pols Help		_					
	Auto Format Archive Sketch	Ctrl+T						
stepper_nano_z	Fix Encoding & Reload		95.b A	tatruit GEX.con Ada	afruit GEX.h	Adafruit SSD1306.cpp	Adafruit_SSD1306.h	E
1 #include "nzs	Serial Monitor	Ctrl+Shift+M	Roar	de Manager				
2	Serial Ploter	Ctrl+Shift+L		no AVR Roards	_			
3 MZS nzs;	WiFi101 Fire ware Updater	/	Ardu	no Yún				
5	Board: "LilyPad Arduino US	в" и	Ardu	no/Genuino Uno				
7 nzs. begin ()	Port: "COM88"	1	Ardu	no Duemilanove or Di	ecimila			
8 }	Get Board Info		Ardu	no Nano	Maga 2560			
9	Programmer: *USBtinvISP*		Ardu	no Mega ADK	Mega 2500			
	Burn Bootloader	1	Ardu	no Leonardo				
2 nzs. loop () :			Ardu	no Leonardo ETH				
3 }			Ardu	no/Genuino Micro				
			Ardu	no Esplora				
			Ardu	no Mini				
			Ardu	no Ethernet				
			Ardu	no Fio				
			Ardu	no BT				
			<ul> <li>LilyPa</li> </ul>	d Arduino USB				
			LilyPa	id Arduino				
			Ardu	no Pro or Pro Mini				
			Ardu	no NG or older				
			Ardu	no Robot Control				
			Ardu	no Robot Motor				

10 / 23

## ③Input "samd"

💿 Boards Manager	
Type All sand	
Arduino SAMD Boards (32-bits ARM Cortex-M0+) by Arduino Boards included in this package: Arduino MKR WiFi 1010, Arduino/Genuino Zero, Arduino/Genuino MKR1000, Arduino MKRZERO, Arduino MKR FOX 1200, Arduino	
MKK WAN 1300, Ardumo MKK GSM 1400, Ardumo MKK NB 1300, Arduino MO Pro, Ardwino MO, Arduino Tian, Adafruit Circuit Playground Express. Online help	
<u>More info</u> 1.6.20 ▼ Install	
Arduino SAMD Beta Boards (32-bits ARM Cortex-M0+) by Arduino Boards included in this package: Arduino MKB Vider 4000	
Online help More info	

## (4) Select development board

ILS AKPI COPE	ex-mu+) by Arauino		20	
r_nano_zer	e   Arduino 1.8.5	In Manageria Malanta	AND THE OWN ADDRESS	
Sketch To	ools] Help			
sketch (re _nano_z ude "nzs zs; setup ()	Auto Format Auto Format Archive Sketch Fix Endoding & Reload Serial Monitor Serial Plotter WiFi101 Firn ware Updater Board: "LilyPad Arduino USB Port: "COM88" Get Board Info Programmer: "USBtinyISP"	Ctrl+T Ctrl+Shift+M Ctrl+Shift+L	△ Boards Manager Arduino SAMD (32-bits ARM Cortex-M0+) Boards Arduino/Genuino Zero (Programming Port) Arduino/Genuino Zero (Native USB Port) Arduino/Genuino MKR1000 Arduino MKRZERO Arduino MKR WiFi 1010 Arduino MKR FOX 1200 Arduino MKR WAN 1300	\$D1306.cpp A
Loop () [	Burn Bootloader		Arduino MKR GSM 1400 Arduino MKR NB 1500 Adafruit Circuit Playground Express Arduino M0 Pro (Programming Port) Arduino M0 Pro (Native USB Port)	

## (5) Choose a port

	Auto Format	Ctrl+T			
	Archive Sketch				
stepper_nano_z	Fix Encoding & Reload		Adafruit_GFX.h	Adafruit_SSD1306.cpp	Adafruit_SSD1306.h
1 #include "nzs	Serial Monitor	Ctrl+Shift+M			
2 175	Serial Plotter	Ctrl+Shift+L			
4	WiFi101 firmware Updater				
5 6 void setup ()	Board: "Artuino/Genuino Zero (Native U	ISB Port)"			
7 nzs. begin ()	Port: "COM90 (Arduino/Genuino Zero (N	lative USB Port))"	Serial ports		
8 }	Get Board Info		COM1		
9	Programmer: "USBtinvISP"		✓ COM90 (Ard	luino/Genuino Zero (Native	e USB Port))
10 11 void loop() {	Burn Bootloader				
12 nzs. loop ();					
13 }					

## **(6)**Compiler without error -> opens the serial monitor



## ⑦Set the baud rate to 115200

Autoscroll New1	ine	Clear output
	230400 baud 250000 baud	-
	500000 baud	E
	2000000 baud	-

Output Choose	"carriage return"	
Autoscroll	and the set printer and last learn	Carriage return V 115200 baud V Clear output
bytes.		Beline Serriage return Both NL & CK

(9)Send a command like "test", When returning to ":>", Representatives can send new orders now

💿 COM90 (Arduino/Genuino Zero (Native USB Port))	
1	Send
test	
Unknown command (try 'help')	
:>	

## DSending "help" will return a list of all commands

💿 COM90 (Arduino/Genuino Zero (Native USB Port))
Send
Unknown command (try help )
nep – pispiays this message
Calibrate - Lalbirates the encoder, Should be done with motor disconnected from machine
getcal - frints the calibration table
testcal - tests the caliberation of the encoder
microsteps - gets/sets the microstep size, example microsteps 10
step - Steps motor one step, optionally arection can be set is step i for reverse
reedback - enable of alsable reedback controller, reedback 0 - alsables, reedback 1 - enables
readpos - reads the current angle as lobit number, applies calibration if valid
encours uses interest encours integnosist
spin with no arguments prints samile input meters, with arguments sets input spin an amere ap, and are insting point numbers with a same argument spin argum
Typin with no agaments prints velociti ind parameters, with arguments sets fild sfild ap Ai Aa where Ap, Ai, Aa are fiosting point numbers maid a side as a water and a state of the state
ppia - with no arguments prints rossiloum. The parameters, with arguments sets rid srid by hinka where Ap, Ai, Aa are floating point numbers dimit, and the set of th
urph with no arguments read arphin setting, with argument sets arrection phrifocation
ensolepinous gets/sets the infortionality of the ensore pin
errorinit gets/set the error limit which will asset error pin (when error pin is set for error output)
ctrimode = gets/set the readokk controller mode of operation
mateurient gets/set tie maximum motor current allowed in militangs
Notecurrent gets/set the motor notating current in minimaps, only used in the simple positional in mode
nomecurrence getsyset the motor moving and nonling currents that will be used when pin RS is now
motorwining getypet the motor wining direction, should only be used by experts
stepsperivation gets/set the motor steps per rotation, should only be used by experts had - B terrs the heal-adam
and - purchased to she built and a in demost 'new 400 1'
move moves encoder or associate angle in degrees move too. I valantite - gatefrat valantite in PPM-
Ventrity grission ventrity in tama Fastarmenst - vasets hard ta fastaru dafanlis
ton - store the motion planner
creps cite motion parmine cateron - set the reference and to zero
data - enables/disables hinary data ontant
Lanting - returns the optical loop processing time
services - returns are control loop processing come
epromite returns include in degrees in error of your un
envolution - forces write of location to envolution
setos - sets the current angle in degrees
reboot - reboots the unit
eepromsetloc - sets the device angle based on EEPROM last reading, compenstates for error
homepin - sets the pin used to drop to homing current
homeangledelay - sets the angle delay in dropping to homing current
home - moves the motor until home switch (enable pin) is pulled low. example 'home 360 0.5' move up to 360 degrees at 0.5 RPM
pinread - reads pins as binary (bit 0-step, bit 1 - Dir, bit 2 - Enable, bit 3 - Error, bit 4 - A3, bit 5- IX, bit 6 - RX
errorpin - Sets the logic level of error pin
geterror - gets current error
getsteps - returns number of steps seen
debug - enables debug commands out USB
♥ Autoscroll       Carriage return →       115200 baud →       Clear output

If the above data appears, it mean that the connection is successful, you can send the following command to modify the parameters.

#### help

The "help"command will return a list of all supported commands.

#### getcal

This command will print out a 200-point calibration table. This is useful if you are doing firmware development and don't want to calibrate each time you update the firmware. You can copy this table into a nonvolatile.cpp file.

#### calibrate

The encoder is calibrated by rotating the encoder 200 times (1.8  $^{\circ}$  each time)

#### testcal

Test calibrate and report the maximum error in degrees

#### step

This will move the motor one step clockwise, based on the current subdivision setting. Use "step 0 16" to move the motor 16 steps clockwise and "step 1 16" to move the motor counterclockwise by 16 steps.

## feedback

This command is used to set whether the control board is in open loop or closed loop.

## Readpos

Report the current position of the motor in degrees

## encoderdiag

Reports the internal registers of the AS5047D encoder to make it easy to check the encoder for problems.

## microsteps

This command gets/sets the current segment

## spid

This command is used to set the Kp, Ki and Kd parameters in the simple positional PID mode.

## ppid

This command is used to set the Kp, Ki and Kd parameters in positional PID mode.

## vpid

This command is used to set the Kp, Ki and Kd parameters in Velocity PID mode.

#### velocity

This command is used to set the speed of motor rotation in velocity PID mode.

#### boot

This command will put the microprocessor into bootloader mode. (can also be done by double-clicking the RESET button)

#### factoryreset

This will erase all parameters of the calibration and settings and reset to factory settings. After executing this command, the motor needs to be calibrated again.

#### Dirpin

"dirpin 0" will set the motor to rotate clockwise when the dir pin is high.

"dirpin 1" will set the motor to rotate counterclockwise when the dir pin is high.

#### errorlimit

Get/set the maximum number of acceptable errors, errorpin will output an error flag when the error exceeds this degree

#### ctrlmode

Gets/sets the controller operating mode. Parameter 0-4 is used to set the current control mode.

0: Controller off :Represents this controller not used

1: Open-Loop : Open loop mode without feedback

- 2: Simple PID :Factory default mode
- **3:** Positional PID
- 4: Velocity PID
- If you are not sure what you are doing, set it to Simple PID.

#### maxcurrent

Set the maximum current of the motor in MA. "maxcurrent 2000" will set the maximum current of the motor to 2000MA.

#### holdcurrent

In Simple PID mode, the minimum current (ie, the current without position error) is holdcurrent. The higher the

Holdcurrent, the higher the temperature of the motor, the greater the noise and the greater the torque.

#### motorwiring

When the stepper motor can be reversed, the direction of rotation will change. The firmware will use the encoder to detect the motor wiring direction and automatically correct the calibration compensation value when the cable is reversely inserted. The direction in which the motor rotates is detected when the factory is first powered up. If the wiring changes afterwards, you can use this command to compensate. However, if the wiring is reversed, it is best to restore the factory settings and recalibrate the motor.

#### stepsperrotation

The firmware will detect the number of steps required per step of the stepper motor at the factory power-on and store it in the flash. This command reads this parameter from flash and allows the user to change this parameter when changing the motor. However, if you replace the motor, it is best to restore the factory settings and recalibrate the motor.

#### move

This command specifies that the motor is rotated to an absolute angular position. And the user can specify the speed of movement (RPM). For example, if the current motor angle is 0, send "move 3600 20" and the motor will rotate 10 turns to  $3600^{\circ}$  at 20RPM. If you send "move 360 0" again, the motor is already at 3600  $^{\circ}$  and it will have no effect.

#### stop

If the move command sent takes a long time to execute, but I want to interrupt the move command and stop now, I can issue the stop command, which will stop the move operation.

#### setzero

This command sets the current motor position to an absolute angle of 0°. Note that if you are executing the move command, the setzero command will take effect immediately, so it is recommended to stop the current move command or wait for the current move command to complete before sending the setzero command.

## 七、(FQA)

Q: Why does the "Waiting MOTO POWER" interface appear after power-on?

A: The processing method and reason after the interface appears:

1, processing method

(1) Re-power on after disconnecting the power.

(2) Remove the control panel behind the motor and check if the magnet is in the center.

2, possible reasons

(1) Artificially rotating the motor after power-on.

(2) There is no firmware in the motherboard connected to the drive adapter board.

Q: After setting the parameters, how did it change?

A: After setting the parameters, you need to wait for 2-5s, then press the reset button of the closed loop drive.

Q: There is firmware, the magnet is in the center. After re-powering, why is the "Waiting MOTO POWER" interface still appearing?

A: Unplug the line above the adapter plate and wait for about 1

#### minute before connecting.

Q: After connecting to the computer with USB, why can't I communicate with the computer?

A: Please check if the driver is installed on the computer (as above). If the driver is ok, it is still not possible to communicate. Please check if the COM port of the debugging tool is consistent with the drive and check if the baud rate is 115200.

#### 八、 matters needing attention

1. When inserting the adapter board, please pay attention to the direction of the adapter board, and do not reverse it.

2. When using for the first time, the closed-loop driver board must be connected to the motherboard with firmware, and then the encoder is calibrated (see the calibration tutorial above). The calibration time takes 1-2 minutes. Please be patient.

3. Check if the driver is installed when connecting to the computer with USB.

4. When the data displayed on the display or serial port is abnormal, please remove the closed-loop drive board and check

if the magnet on the motor shaft is in the center position. If not, please return to the center.

5. Do not set it immediately after power-on, and wait for initialization (3-5s) before setting parameters.

6. Please do not manually turn the motor after power-on.